



Biosampling Reinvented™

## OMICS-WATER Collection

Instructions for collecting waste water or water samples

- 1 Unscrew the collection tube with grey cap
- 2 Add sample water or waste water to the max fill line



Maximum Fill Line

- 3 Screw the grey cap back on tightly  
(note: Make sure it is closed tight)
- 4 Mix the sample for 10 seconds
- 5 The collected sample is now ready to be shipped at room temperature by regular mail or standard courier service to the processing lab